



\varnothing	0080	0100	0115	0120	0130	0140	0150	0160	0180	0200	0225	0250	0300	0350	0400	0450	0500	0550	0600
B	195	215	230	235	245	255	265	275	295	315	340	365	415	465	515	565	615	665	715
C	230	250	265	270	280	290	300	310	330	350	375	400	450	500	550	600	650	700	750
E	635	655	670	675	685	695	705	715	735	755	780	805	855	910	960	1010	1060	1110	1160
F	630	650	665	670	680	690	700	710	730	750	775	800	850	900	950	1000	1050	1100	1150
kg	2,6	2,8	2,9	3	3	3,1	3,2	3,4	3,5	3,7	3,9	4,1	4,6	5	5,5	6	6,5	7	7,6

notes:	DIN ISO 13920 Tolerances B				 Jeremias [®] CHIMNEY SYSTEMS				scale
	revisions-no.								1:12
	date		name		description Flashing kit 5-15°, incl.storm collar	format			
	drawn by		JMA			A4			
	checked by		SWA			sheet			
	approved by		JWY			1 of 1			
modified by				code					
				DWECO81					
				drawing-no.	02-35-5301-000				